










Motion Controllers

2.028 Controller overview


SMC-series

| | Version | Form-Factor | Stepper Motor | DC-brushed Motor | DC-brushless Motor | Piezo-Motor | 2-Phase Linear/Torque | 3-Phase Linear/Torque | Closed-Loop | Communication | Modes of Motion | Number of Axes | Index |
|---|----------------|--|---------------|------------------|--------------------|-------------|-----------------------|-----------------------|---|--|--|---|-------|
| | | | | | | | | | | | | | |
|  | SMC corvus | desktop 19" rack | ■ | | | | | | yes / optional | RS-232 Ethernet TCP/IP GPIB | linear interpolation | 2 or 3 (n x 3) | 2.032 |
|  | SMC corvus eco | desktop | ■ | | | | | | yes / optional | RS-232 USB | linear interpolation | 2 or 3 (n x 3) | 2.034 |
|  | SMC corvus pci | PCI-board | ■ | | | | | | yes / optional | PCI-COM RS-232 | Linear interpolation | 2 or 3 | 2.036 |
|  | SMC pollux | desktop 19" chassis intelligent motor | ■ | | | | | | yes / optional | RS 232 Ethernet TCP/IP USB-cable | point to point | 1, daisy chain up to 16 | 2.038 |
|  | SMC hydra | desktop CM/TT 19" RM | ■ | ■ | ■ | ■ | ■ | ■ | yes / optional absolute encoder optional: 1Vpp and RS-422 | RS-232 Ethernet TCP/IP | point to point linear interpolation | 2 | 2.040 |
|  | SMC pegasus | SMC taurus: desktop SMC pegasus: 19" rack | ■ | | | | ■ | ■ | yes / optional | RS-232 | point to point | SMC taurus: 1 SMC pegasus: up to 256 | 2.042 |


SM-series

| | Version | Form-Factor | | | | | | | Closed-Loop | Communication | Modes of Motion | Number of Axes | Index |
|--|---------|-------------|---|--|--|--|--|--|-------------|---------------|-----------------|----------------|-------|
| | | | | | | | | | | | | | |
|  | SM-32 | PCI-board | ■ | | | | | | no | PCI-bus | point to point | 3 | 2.044 |


LMC-series

| | Version | Form-Factor | | | | | | | Closed-Loop | Communication | Modes of Motion | Number of Axes | Index |
|---|---------|------------------|--|---|---|--|--|---|-------------|--------------------|-----------------|----------------|-------|
| | | | | | | | | | | | | | |
|  | LMC-100 | pocket / desktop | | ■ | ■ | | | ■ | yes | RS-232 CAN-open | point to point | 1 | 2.045 |



MoCo-series

| | Version | Form-Factor | | | | | | | Closed-Loop | Communication | Modes of Motion | Number of Axes | Index |
|---|---------|------------------|--|---|--|--|--|--|-------------|---------------------|-----------------|-------------------------|-------|
| | | | | | | | | | | | | | |
|  | MoCo DC | pocket / desktop | | ■ | | | | | yes | RS 232 USB-cable | point to point | 1, daisy chain up to 16 | 2.046 |


MMC-series

| | Version | Form-Factor | Stepper Motor | DC-brushed Motor | DC-brushless Motor | Piezo-Motor | 2-Phase Linear/Torque | 3-Phase Linear/Torque | Closed-Loop | Communication | Modes of Motion | Number of Axes | Index |
|---|-------------|-------------------|---------------|------------------|--------------------|-------------|-----------------------|-----------------------|------------------------------------|---------------|-----------------|-------------------------|-------|
| | | | | | | | | | | | | | |
|  | MMC-100/110 | desktop stackable | | | | ■ | | | yes incremental RS-422 1Vpp* | USB | point to point | 1, daisy chain up to 99 | 2.048 |

Piezo-series


| | Version | Form-Factor | Stepper Motor | DC-brushed Motor | DC-brushless Motor | Piezo-Motor | 2-Phase Linear/Torque | 3-Phase Linear/Torque | Closed-Loop | Communication | Modes of Motion | Number of Axes | Index |
|---|---------------|-------------|---------------|------------------|--------------------|-------------|-----------------------|-----------------------|-------------|---------------|----------------------------------|----------------|-------|
| | | | | | | | | | | | | | |
|  | PiCo 33 Piezo | desktop | | | | ■ | | | no yes | RS-232 USB | point to point point to point | 3 3 | 2.050 |
|  | PMA-100 | desktop | | | | ■ | | | no | PCI-Bus | | 1 | 2.051 |

DMC-series


| | Version | Form-Factor | Stepper Motor | DC-brushed Motor | DC-brushless Motor | Piezo-Motor | 2-Phase Linear/Torque | 3-Phase Linear/Torque | Closed-Loop | Communication | Modes of Motion | Number of Axes | Index |
|---|----------------|---|---------------|------------------|--------------------|-------------|-----------------------|-----------------------|-------------|-------------------------------|--|----------------|-------|
| | | | | | | | | | | | | | |
|  | DMC Controller | PC based PCI-Slot external 19"-chassis | ■* | ■* | ■* | ■* | ■* | ■* | yes | PCI-Bus Ethernet RS-232 | Linear interpolation Circular interpolation Contouring independant | 1..8 | 2.052 |

*in combination with MPA


Delta-Tau-series

| | Version | Form-Factor | Stepper Motor | DC-brushed Motor | DC-brushless Motor | Piezo-Motor | 2-Phase Linear/Torque | 3-Phase Linear/Torque | Closed-Loop | Communication | Modes of Motion | Number of Axes | Index |
|---|--------------------|---------------|---------------|------------------|--------------------|-------------|-----------------------|-----------------------|-----------------------|---------------------------|--|----------------|-------|
| | | | | | | | | | | | | | |
|  | Geobrick / Clipper | 19" rackmount | ■ | ■ | ■ | ■ | ■ | ■ | yes RS-422 1Vpp | Ethernet USB RS-232 | Linear interpolation Circular interpolation Contouring independant | 4 / 8 | 2.054 |

FlexMotion-series

| | Version | Form-Factor | Stepper Motor | DC-brushed Motor | DC-brushless Motor | Piezo-Motor | 2-Phase Linear/Torque | 3-Phase Linear/Torque | Closed-Loop | Communication | Modes of Motion | Number of Axes | Index |
|---|-------------------------|----------------------------|---------------|------------------|--------------------|-------------|-----------------------|-----------------------|-------------|---------------|--|----------------|-------|
| | | | | | | | | | | | | | |
|  | Flex Motion Controllers | PC based PCI / PXI Slot | ■ | | ■ | | | | yes | PCI/PXI-Bus | Linear interpolation Circular interpolation Contouring independant | 2/4 2/4/6/8 | 2.056 |

Power Amplifiers

| | Version | Form-Factor | Stepper Motor | DC-brushed Motor | DC-brushless Motor | Piezo-Motor | 2-Phase Linear/Torque | 3-Phase Linear/Torque | Closed-Loop | Communication | Modes of Motion | Number of Axes | Index |
|---|---------|-------------|---------------|------------------|--------------------|-------------|-----------------------|-----------------------|-------------|---------------|-----------------|----------------|-------|
| | | | | | | | | | | | | | |
|  | MPA | 19" rack | ■ | ■ | ■ | ■ | ■ | ■ | DMC-series | | | 1..8 | 2.058 |

APPLICATIONS

CONTROLLERS

ROBOTICS

LINEAR STAGES

ROTATION STAGES

PIEZO STAGES

MANUAL STAGES

ACCESSORIES

APPENDIX

SMC-SERIES

SM-SERIES

LMC-SERIES

MoCo-SERIES

PIEZO-SERIES

DMC-SERIES

FLEX MOTION-SERIES

MPA POWER AMPL.

SOFTWARE

Our SMC family of motion controllers is based on modern 32 bit technology which enables performances of stepper motor driven systems which haven't been possible before. A so-called \sin^2 acceleration offers very smooth acceleration and deceleration of the motors which allows highest performance positioning in the nanometer range. One of the big advantages of our SMC controllers is the possibility to drive the stages with extremely high resolution.

In Figure 1 you can see the measurement results of 100 nm steps driven with a PLS-85 stage with 2 phase stepper motor in open loop (without feedback of an encoder system). The stage is moving these steps with high precision. Driving the stage with 25 nm steps (Figure 2) it is obvious that the step width shows more variations, but in average the value is about 25 ± 5 nm. Positioning in the nm range is normally done with piezo drivers. But even with a standard linear stage like PLS-85 and our SMC-controllers it is possible to push the stage in the nm range. In Figure 3 you can see the result of programmed 10 nm steps measured by an interferometer. The stage is not moving in equal 10 nm steps, but the average motion is in this range. The measurement is limited by the 5 nm resolution of the interferometer. This amazing resolution is not possible with any other typical stage.




Figure 1: PLS-85, 2 SM open loop, resolution with 100 nm steps




Figure 2: PLS-85, 2 SM open loop, resolution with 25 nm steps




Figure 3: PLS-85, 2 SM open loop, resolution with 10 nm steps

APPLICATIONS

CONTROLLERS

ROBOTICS

LINEAR STAGES

ROTATION STAGES

PIEZO STAGES

MANUAL STAGES

ACCESSORIES

APPENDIX

SMC-SERIES

Technical Info

SMC corvus

SMC corvus eco

SMC corvus pci

SMC pollux

SMC hydra

SMC pegasus

SM-32

LMC-100

MoCo DC

MMC-100/110

PiCo 33 Piezo

PMA-100

DMC Controller

Geobrick / Clipper

Flex Motion Controllers

MPA

For example, our VT-80 stage can be “positioned” with 100 nm steps (figure 4) but the result is not visible in defined levels and constant step width which is mainly due to the fine pitch leadscrew.

On the other hand the results of a PLS-85 stage shown in Figure 1-3 can be improved by driving the stage in closed loop. One of the advantages of our SMC-controllers is the intelligent control of the stage by using the 1 Vpp interface of a high resolution scale. Figure 5 shows the measurement of a LS-110 stage with a linear scale. The resolution of 50 nm is visible in well defined moving steps. Even changing the load does not disturb the stage positioning. The resolution is limited by the scale system, so using a 2 nm scale enables resolutions of 2 nm which can be influenced by environmental disturbances like temperature drift (for example, a change of 0.01 degree in the temperature is resulting in a stage expansion of about 10 nm).

For these type of applications we designed our ultra-precision stages UPM-160 and NPE-200 or customized granite based setups using Heidenhain Zerodur scales.




Figure 4: VT-80, 2 SM open loop, resolution with 100 nm steps




Figure 5: LS-110, 2 SM closed loop 1 Vpp, resolution with 50 nm steps

Speed is one important parameter for setting up a system. Often the maximum speed is required but for other applications it is very important to drive very slow and smooth. Standard stepper motor controllers cannot drive smooth. Even DC servo motors are not able to drive in the low velocity range in a linear and smooth way.

Figure 6 shows the measurement of a PLS-85 stage with linear scale (with a 10 nm encoder resolution). The speed was set to 100 nm/s, so the stage traveled 360 μm within one hour, or about 10 mm per day. The movement is very smooth.

Figure 7 shows the first 100 nm of the travel.

Here it is important to realize that the interferometer resolution is 5 nm which results in the step-wise diagram. These steps are not coming from the stage. The movement is much smoother. It is very important to understand that the speed is linear and variations are in the 1 nm/s range which is exceptional for a loaded stage with several mm travel range. The results can be also improved by using a better encoder resolution. The result of a UPM-160 stage controlled with 45 nm/s speed is shown in Figure 8. The 450 nm move within 10 seconds is very linear. The interferometer resolution is limiting the interpretation of the picometer-per-second scale.




Figure 6: PLS-85, 2 SM closed loop, speed with 100 nm/s




Figure 7: PLS-85, 2 SM closed loop, speed with 100 nm/s




Figure 8: UPM-160, 2 SM open loop, speed with 45 nm/s

APPLICATIONS

CONTROLLERS

ROBOTICS

LINEAR STAGES

ROTATION STAGES

PIEZO STAGES

MANUAL STAGES

ACCESSORIES

APPENDIX

SMC-SERIES

Technical Info

SMC corvus
SMC corvus eco
SMC corvus pci
SMC pollux
SMC hydra
SMC pegasus
SM-32
LMC-100
MoCo DC
MMC-100/110
PiCo 33 Piezo
PMA-100
DMC Controller
Geobrick / Clipper
Flex Motion Controllers
MPA

Positioning accuracy is normally limited by the quality of the bearings and drive mechanism, so for example errors in the leadscrew pitch are resulting in a positioning error. Figure 9 shows the deviation of the position between desired and measured position. Within a travel range of 100 mm the LS-180 stage has a positioning error of about 32 μm . The measurement shows both travel directions, so that the bidirectional repeatability, which depends on the backlash, can be seen with a value of 1.78 μm .

For some applications it is important to improve the absolute positioning, whereas the bidirectional repeatability is not important. The problem can be solved by using the deviation measurement for a position correction inside the SMC controller (see position correction option in SMC Corvus). The result is presented in Figure 10 which looks crowded at a deviation scale of 3 μm . The deviation is minimized by a factor of 10, eliminating the slope grading. This is a cost effective method to minimize system positioning errors. By using a linear scale system, the repeatability and accuracy can be further improved.




Figure 9: LS-180, 2 SM open loop, positioning error




Figure 10: LS-180, 2 SM open loop, position corrected



Pocket Box Controller / Motor & Controller System

KEY FEATURES

- Single axis microstep controller system
- Stand alone system, or with integrated 2-phase stepper motor
- High resolution microstep
- Up to 16 SMC pollux can be combined with only one RS-232 interface
- DSP controller type
- Velocity range $<0.1 \mu\text{m/s} \dots 40 \text{ rev/s}$ (200 step motor)
- Serial interface RS-232 19200 Baud
- Venus 2 compatible string based command language
- Windows™ user interface
- 24 VDC power supply (external)
- Synchron motion start commands
- Speed mode
- Closed-loop 1 Vpp interface, optional for NT series
- Mixed configurations (open-loop / closed-loop) possible with NT series
- LabVIEW™ VIs
- Windows DLL and open source project available
- 3 types with different torques / velocities available

TECHNICAL DATA

| | |
|---|---|
| Axes | 1 axis, 2 phase stepper motors |
| Computer interface | RS-232 19.2 kBaud |
| Commands | Venus-2 ASCII |
| Supply voltage | 24 VDC |
| Phase currents | $\leq 1.2 \text{ A/phase}$ |
| Limit switches | 2 per axis software configurable |
| Velocity range | For 200 step motor $<0.1 \mu\text{m/s} \dots 13 \text{ rev/s}$ TYPE I $<0.1 \mu\text{m/s} \dots 25 \text{ rev/s}$ TYPE II $<0.1 \mu\text{m/s} \dots 50 \text{ rev/s}$ TYPE III |
| Max. resolution | 300 000 positions/rev. |
| Max linear resolution | 1 nm |
| Program and parameter | Flash memory |
| Amplifier | 24 V bipolar 2 phase, with short-circuit & temperature protection |
| Version with integrated 2-Phase stepper motor | |
| Motor torque | 160 mNm (Type I) 160 mNm (Type II) 320 mNm (Type III) 900 mNm (Type II HT) |
| Housing | Pocket desktop (without motor), or motor/controller HxWxD 48x56x97 mm (additional motor shaft 20 mm) |
| | 19" chassis SMC-pollux integration box: 3HE 84TE chassis with 90..230 VAC power |
| Software Interface | Windows demo program SMC_Pollux DLLs, demo applications (C/Delphi/VB) LabVIEW™ VIs and demo application |

Pollux box controller

| | |
|-----------------------------|-----|
| Type I | 511 |
| Type II | 512 |
| NT-Type I | 516 |
| NT-Type II | 517 |
| NT-closed loop 1Vpp Type I | 514 |
| NT-closed loop 1Vpp Type II | 515 |
| Type I OEM | 518 |
| NT-Type I OEM | 519 |

Pollux motor & controller

| | |
|----------------------|-----|
| Type I (160 mNm) | 501 |
| Type II (160 mNm) | 502 |
| Type III (320 mNm) | 503 |
| Type II HT (900 mNm) | 504 |

Pollux multiaxis desktop

| | |
|--------------------------------------|-----|
| Pollux 6 axis desktop | 557 |
| Pollux 3 axis desktop TCP/IP | 558 |
| Pollux 4 axis desktop TCP/IP | 559 |
| Pollux NT 3 axis desktop closed-loop | 564 |

Pollux accessories

| | | |
|------------------------|--|-----|
| Interfacing | RS-232 cable RJ45-RJ45, 0.5 m | 524 |
| | length to combine 2 pollux controller | |
| | RS-232 cable DSub9-RJ45, 2 m | |
| | length for PC connection | |
| | Ethernet TCP/IP Interface DIN-Rail | 545 |
| Power supply | 60 W, 90-264 VAC | 522 |
| Mounting | DIN rail mounting-kit | 530 |
| Modular chassis | 4 Axes chassis 19" 3HE 84TE | 550 |
| | 8 Axes chassis 19" 3HE 84TE | 551 |
| | 12 Axes chassis 19" 3HE 84TE | 552 |
| | 16 Axes chassis 19" 4HE 84TE | 553 |
| | CL 4 Axes chassis 19" 3HE 84TE | 554 |
| | CL 6 Axes chassis 19" 3HE 84TE | 555 |
| | CL 8 Axes chassis 19" 4HE 84TE | 556 |
| | Ethernet TCP/IP Interface for pollux chassis | 544 |

The Pollux-Chassis 19 includes power-supply (90-230VAC), RS-232 interface, interlock input, power-mains, netfilter/fuse



Pocket Box Controller Closed Loop



SMC pollux 16 Axes 19" 4H 84T



Motor & Controller System with VT-80, see page 4.112



SMC pollux network (2-axes), DIN rail

APPLICATIONS

CONTROLLERS

ROBOTICS

LINEAR STAGES

ROTATION STAGES

PIEZO STAGES

MANUAL STAGES

ACCESSORIES

APPENDIX

SMC-SERIES

Technical Info

SMC corvus

SMC corvus eco

SMC corvus pci

SMC pollux

SMC hydra

SMC pegasus

SM-32

LMC-100

MoCo DC

MMC-100/110

PiCo 33 Piezo

PMA-100

DMC Controller

Geobrick / Clipper

Flex Motion Controllers

MPA

7160-9-

APPLICATIONS

CONTROLLERS

ROBOTICS

LINEAR STAGES

ROTATION STAGES

PIEZO STAGES

MANUAL STAGES

ACCESSORIES

APPENDIX

SMC-SERIES

Technical Info

SMC corvus

SMC corvus eco

SMC corvus pci

SMC pollux

SMC hydra

SMC pegasus

SM-32

LMC-100

MoCo DC

MMC-100/110

PiCo 33 Piezo

PMA-100

DMC Controller

Geobrick / Clipper

Flex Motion Controllers

MPA

| Order No. | 7145-9 | | | | |
|---|--------|--|--|--|--|
| Number axes (1..8 axes) | n | | | | |
| Amplifier DC-brush 2 A | 0 | | | | |
| Amplifier DC-brush 5 A | 1 | | | | |
| Amplifier 2SM microstep 24 V 2 A | 3 | | | | |
| Amplifier 3-Phase brushless 24 V 5 A | 4 | | | | |
| Amplifier DC brush 12 V 1 A | 5 | | | | |
| Amplifier 3-Phase linear/torque motor | 6 | | | | |
| Amplifier Piezo-Motor Driver (PMA-100) | 7 | | | | |
| Interface to NI Flexmotion Controller | 0 | | | | |
| Interface to DMC PCI controller | 1 | | | | |
| Interface to DMC Ethernet/RS-232 Controller | 2 | | | | |
| Interface to Delta-Tau PMac Controller | 3 | | | | |
| Interface to Delta-Tau UMac Controller | 4 | | | | |
| Interface to others | 9 | | | | |
| 12 VDC 100 W | 0 | | | | |
| 24 VDC 150 W | 1 | | | | |
| 24 VDC 220 W | 2 | | | | |
| 48 VDC 220 W | 3 | | | | |
| others | 9 | | | | |

USA (East) & CANADA

PI (Physik Instrumente) L.P.
16 Albert St.
Auburn, MA 01501
Tel: +1 (508) 832 3456
Fax: +1 (508) 832 0506
Email: info@pi-usa.us
www.pi-usa.us

USA (West) & MEXICO

PI (Physik Instrumente) L.P.
5420 Trabuco Rd., Suite 100
Irvine, CA 92620
Tel: +1 (949) 679 9191
Fax: +1 (949) 679 9292
Email: info@pi-usa.us
www.pi-usa.us

GERMANY

Headquarters:
PI miCos GmbH
Freiburger Strasse 30
D-79427 Eschbach
GERMANY

Phone: +49 7634 50 57 0
Fax: +49 7634 50 57 393
e-mail: info@pimicos.com
home: www.pimicos.com

**Physik Instrumente (PI)
GmbH & Co. KG**
Auf der Römerstraße 1
76228 Karlsruhe/Palmbach
Tel: +49 (721) 4846-0
Fax: +49 (721) 4846-1019
Email: info@pi.ws
www.pi.ws



Call Us Today
508.832.3456 (East)
949.679.9191 (West)